


A200

1/2" - 2"



American Backflow
Products Company



Modification Overview

Production of the A200 (Watts 800M4) began in 1997 and is the current model.



Hood Removal

The 1/2" - 3/4" hood is secured by two screws.

The 1"-2" hood is secured by two screws.



Bonnet Removal

The bonnet is threaded into the body and sealed by an o-ring.

There is no spring load.



Float Removal and Service

The float is free once the bonnet has been removed.

Replace the rubber seal by pulling it from the groove on the float.



Check Valve Removal

Check valve is spring loaded.

Remove spring retainer by pressing down and rotating to clear tabs on the body.

Remove spring and poppet.



Check Disc Replacement

Replace the rubber disc by pulling it from the groove on the poppet.



 American Backflow
Products Company



 American Backflow
Products Company

Check Seat Replacement

The check seat is threaded into the body and sealed by an o-ring.

Note: A special tool is needed to remove the seat.



Reassembly Notes

Reassemble in reverse order.

Place large end of spring down in body.

The guides on the retainer face up.

The guides on the float face up.

Make sure the float spring is centered on the float.

