EXT-14 / EXT-18 Pipe Extractors for Broken Test Cocks

Models:

EXT-18 (Small) $^{1}/_{8}$ " Male thread test cock

EXT-14 (Large) $^{1}/_{4}$ " Male thread test cock

Use:

To remove broken male thread end of test cock from device body.



Insert tip of tool into broken end of pipe and tap lightly to secure.



Use an adjustable wrench to turn tool counter clockwise until broken end is removed.



